SMALL CRANES with counterweight



ITI500B



At a glance

| LIFTING | |
|--------------------------|---|
| manual | × |
| Compact hydraulic system | × |
| Hydrobull pump | × |
| electric | ~ |

| DRIVING | |
|-----------------|-----------------------|
| manual | ~ |
| Steering handle | ✓ |
| FaPo | × |
| electric | × |

| LIFTIN | G CAPACITY WITH HORIZONTAL JIB | |
|--------|--|---|
| | max. 500 kg in front of the wheels | ~ |
| 3 | 220 kg at 1700 mm in front of the wheels | ~ |

| OPERATING FREQUENCY | |
|-------------------------------|----------|
| up to 10 times per month | × |
| up to 25 times per month | × |
| up to 100 times per month | ~ |
| more than 100 times per month | × |

SMALL CRANES with counterweight

ITI500B



This original Elektrobull crane with counterweight has a rear-mounted chassis and its special curved design hides the counterweight filling, which is installed on site. In contrast to its brother, the ITI500N, lifting and lowering functions are conveniently carried out at the touch of a button.

It is driven by pulling and pushing on the manual steering handle.



LIFTING/LOWERING

Secured on the high-quality, galvanized DIN safety hook **battery-powered at the push of a button on the manual switch.** Using the manual switch with approx. 3 metres of cable, the operator can flexibly operate the lifting and lowering independently of the crane. This means You can stand close to the load to observe or assist the exact fitting. This gives more security and allows tasks to be completed faster.

Driving

Manually by pulling and pushing on a steering handle that can be turned almost up to 180 degrees.

JIB

Has five settings, which can be easily selected by simply pulling out the telescopic jib with a socket pin system.

PARKING

By raising the steering handle, the crane is automatically locked for idle periods. Manual machines are generally not equipped with a travel brake.

COUNTERWEIGHT

Is installed in the machine on-site and is included in the price. This serves to stabilise the crane and cannot be removed.


OTHER

- Modern, protected design only from Hydrobull
- Delivery incl. declaration of conformity and operating instructions
- German Product
- Euronorm 2006/42/EC and DGUV68
- 2 Year Warranty



with counterweight

Technical Drawings ITI500B





Technical specifications ITI500B

RATIO LIFTING CAPACITY, OUTREACH, LIFTING HEIGHT

| Jib | Lifting capacity/kg | Load with horizontal jib/mm | | | Lift height*/mm | |
|----------|------------------------|--|--------------------------------|------|-----------------|--|
| Position | | in front of the hydraulic system approx. | in front of the wheels approx. | min. | max. | |
| 1 | 500 | 700 | 540 | 620 | 2160 | |
| 2 | 380 | 990 | 830 | 380 | 2345 | |
| 3 | 305 | 1280 | 1120 | 140 | 2530 | |
| 4 | 255 | 1570 | 1410 | 0 | 2715 | |
| 5 | 220 | 1860 | 1700 | 0 | 2900 | |

 $\,$ * at hook mouth opening - please refer to the diagram for the reduced outreach

| OTHER DETAILS | | min. | max. |
|--|----|------|--------|
| Jib length from to | | 1045 | 2205 |
| Length of wheelbase | mm | | 1500 |
| Length of chassis incl. wheels | mm | | 2300 |
| Length incl. inserted lowered jib Pos. 1 | mm | | 2170 |
| approx. aisle width for 90° turn | mm | | 2200 |
| Width of chassis external | mm | | 800 |
| Width of chassis internal | mm | | - |
| Clearance height, jib horizontal | mm | | 1875 |
| Clearance height, jib lowered | mm | | 1600 |
| Clearance | mm | | - |
| Hook length approx. | mm | | 225 |
| Ground clearance | mm | | 30 |
| Load wheel | mm | | 150 |
| Steering wheel | mm | | 150 |
| Slewing | | | |
| Tare weight - incl. counterweight filling | kg | | 800 kg |
| Required filling weight for counterweight cranes** | kg | | - |
| Batteries | AH | | 70 |
| External charger | А | | 10 |
| ** Machine can only be used when installed | I | | |